

## PA600<sup>[1]</sup> UPDATE GUIDE

The following instructions show the procedure to update software of Pa600:

1. Insert into USB port of Pa600 an USB stick containing the PKG file;
2. Turn on Pa600 while keeping pressed **INTRO 1**, until Pa600 shows the words “*System update*” just under the KORG logo at the initial black & white screen. Then release INTRO 1.
3. Execute touch screen calibration (press the red crosses shown on the screen);
4. Use the combo-box in the bottom-left of the screen to select the USB stick containing the PKG file. Then use the file browser window to select the PKG;
5. Press **Select** button in the bottom-right of the page;
6. Press **Update** button in the next window;
7. Wait for the system reboot;
8. Wait for the system update goes on and for the message “*SYSTEM UPDATE COMPLETED. Please turn the instrument off.*”;
9. Turn off the instrument.

[1] It is intended any customization of Pa600, including Pa600-QT.